

Post-It Box PATTERN

1. Trace pattern onto a light-weight cardboard.
2. Cut around entire pattern.
3. Cut the middle two lines (marked with scissors) to the dot.
4. Score all other interior lines.
5. Using the score lines, fold into a box and adhere sides.
6. Add magnets to the back side.

*Notes: If you are covering the box with paper, cover the pattern *before* you fold and adhere. Overlap about 1" on back panel.

